

ART. 3001

3000 Smart Series "3+1" and "4+1" audiophone incorporating both AC buzzer call input and an adjustable electronic call tone input and "door open" push button.

For use on traditional "3+1" audio systems that require an electronic call tone including the following audio kits: 4K series, 8K series and VR120DK series kits. Can also be used on traditional "4+1" audio and video systems that require an AC buzzer call.

Call tone adjustment: 3 level (low, medium and high) call tone switch.




3001 Smart Series Audiophone QUICK GUIDE







During a call (call tone or AC buzzer call)



pick up the handset.





With the handset lifted a conversation with the caller can begin.




To end the call replace the handset back on the cradle.

TO OPEN THE DOOR







With the handset lifted, press the lock button [○]¬ to operate the lock.




To end the call replace the handset back on the cradle.

CALL TONE VOLUME ADJUSTMENT (CALL TONE ONLY)






Move the volume switch to the lower position to set the call tone volume to low.



Move the volume switch to the middle position to set the call tone volume to medium.



Move the volume switch to the higher position to set the call tone volume to high.

TECHNICAL ADVICE

For further technical advice and assistance on the installation of this product please contact Videx technical on tel: 0191 224 3174.

For any sales advice and assistance please contact Videx sales on tel: 0191 238 8324.

To download a copy of this quick guide visit the Videx website: www.videxuk.com

